



American Party Place
4522 S Tacoma Way, Tacoma, WA 98409
253-473-3300
www.americanpartyplace.com

Chafing Dishes 8qt, 4qt, 3qt

Chafing dishes will not cook food, so make sure that all food is fully cooked before putting it out to serve!

Operating Instructions:

- 1) Place chafing dish on a sturdy surface so that all four feet are flat.
Pour **HOT** water into the water pan so that it fills the pan with $\frac{3}{4}$ to $1\frac{1}{2}$ inches of water.
 - 2) Fill food insert dish with **HOT** food that you want to keep hot during your event. Place the food pan into the water pan.
 - 3) Open can(s) of chafing dish fuel by pulling off the lid. Light the sterno and place them in the cups under the chafing dish.
 - 4) Adjust the lid of the heat cup so that it is halfway open. This will prevent overheating. Sterno fuel is good for two hours!
 - 5) Stir food occasionally in the food in the food pan. Keep the lid on the food when you are not serving.
 - 6) Tilt up one side of the chafing dish every 30 minutes. If you hear a sizzling sound, you need to add more water to the water pan.
- Do not use anything but **STERNO TYPE FUEL** in burner
 - **NEVER** light the burner unit before putting liquid into the water pan (low flame if sufficient to maintain proper heat in an indoor situation)
 - Do not put the unit on a hot stove or open flame.

Cleaning Instructions:

Before returning chafing dish, wash out the food pans. Wash the chafing dish and the food pans in lukewarm water and a mild dish detergent.
NEVER USE HARSH ABRASIVES TO CLEAN THE CHAFING DISH.