



American Party Place
4522 S Tacoma Way, Tacoma, WA 98409
253-473-3300
www.americanpartyplace.com

HOT DOG ROLLER

WARNING! Connect the cord to a suitable outlet and be certain no other equipment is operating from the same outlet! Failure to do so **WILL** reduce this unit's output and performance!

Operating procedures:

- 1) Machine will accommodate up to **18 standard hot dogs** at one time!
- 2) Place hot dogs on the rollers and turn heat to designated temperature.
 - * **Left knob controls 5 front rollers**
 - * **Right knob controls 5 rear rollers**
- 3) Determine level of heat required choosing from one of three settings:
Low, Medium, and High.
- 4) Approximated cooking time is 20-25 minutes @ medium or high setting for standard hot dogs! Holding cooked hot dogs at a warm temperature is acceptable for short periods of time!

Cleaning Instructions:

1. Unplug the power cord from the outlet
2. Remove any remaining hot dogs from the rollers, and wipe rollers down
3. Remove drip pan and clean thoroughly then reinsert the pan.